


WIRE/HOSE ROUTING

CONTENTS


WIRING DIAGRAM.....	10- 2
DF25	10- 2
DF25E.....	10- 3
DF25R.....	10- 4
WIRE ROUTING	10- 5
FUEL HOSE ROUTING	10- 9

WIRING DIAGRAM


DF25




DF25E





DF25R





WIRE ROUTING









FUEL HOSE ROUTING

CAUTION

- Do not over-bend (kink) or twist hoses when installing.
- When installing hose clips, position tab to avoid contact with other parts.
- Check that hoses do not contact rods and levers during either engine operation or standstill.
- Extreme care should be taken not to cut, abrade or cause any other damage on hoses.
- Care should be taken not to cause hoses to be compressed excessively by any clamp when fitted.

